

**Schurter**

## CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S

Gawo la Nambala:	CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S
Wopanga / Chinthu:	Schurter
Mafofokozedwe Akatundu	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S.pdf</a>
Mkhalidwe wa RoHS	Kutsogolera / RoHS Kumvera
Chombo Chochokera	Hong Kong
Njira Yopereker	DHL/Fedex/TNT/UPS/EMS

PEMPHO LA QUOTATION

Chithunzi chingakhale choyimira. Onani ndondomeko zogwiritsira ntchito mankhwala.

### Mafofokozedwe a CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S

GAWO LA NAMBALA	CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S
WOPANGA	Schurter
KUFOTOKOZERA	SWITCH PUSHBUTTON SPST 100MA 42V
MKHALIDWE WOPANDA UFULU / MKHALIDWE WA ROHS	Kutsogolera / RoHS Kumvera
TSAMBA LAZAMBIRI	<a href="#">CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S.pdf</a>
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
LEMBANI	Capacitive, Illuminated
NJIRA YOTHETSER	Wire Leads
SINTHA NTCHITO	Off-On
MNDANDANDA	CPS
PANEL CUTOUT DIMENSIONS	Circular - 19.10mm Dia
KUPAKA	Bulk
KUTENTHA KWAMBIRI	-40°C ~ 60°C
MTUNDU WOKWERA	Panel Mount, Front
MPHUNO YOPANDA CHISOKONEZO (MSL)	1 (Unlimited)
MECHANICAL LIFE	-
MKHALIDWE WOPANDA UFULU / MKHALIDWE WA ROHS	Lead free / RoHS Compliant
CHITETEZO CHA INGRESS	IP67 - Dust Tight, Waterproof
KUUNIKIRA VOLTAGE (DZINA)	5 ~ 28 VDC
MTUNDU WA KUUNIKA, MTUNDU	LED, Red/Magenta
MAWONEKEDWE	Ceramic Actuator, Finger Guide, Root Symbol
MOYO WA MAGETSI	-
KUFOTOKOZEDWA KWAMBIRI	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
KUWONETSER	100mA (AC/DC)
MAKANEMA - ACTUATOR / CAP	Clear (White Filter/Diffuser)
DERA	SPST
MTUNDU WOTSATSA	Round, Button, Flush

### Matanthauzo okhudzana

Schurter CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	Wogulitsa CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	Wothandizira CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S
Mtengo wa CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	Zithunzi za CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	Chithunzi cha CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S
Datasheet ya PDF ya CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S Tsitsa Datasheet	Datasheet ya CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S
CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S Stock	Gulani CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	Gulani Schurter CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S
Schurter CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	Wothandizira Schurter	Wopatsa Schurter
Schurter CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	Schurter Inc. CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1052-S	

### Zogwirizana

<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1058-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1056-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1054-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1046-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1050-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1049-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1057-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1055-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1053-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1048-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1047-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTWF-AI0RMVAR-W1051-S</b></p> <p>Opanga: Schurter Kufotokozer: SWITCH PUSHBUTTON SPST 100MA 42V Zilipo: Out stock</p> <p style="text-align: center; background-color: #d3d3d3; padding: 5px; font-weight: bold;">RFQ</p>